Equipment manual F-250

OVERVIEW

Use this matrix only for the equipment identifier above.

FAULT MATRIX

Fault	Reading	Required action
FILTER BLOCKAGE	101	Inspect filter
SEAL WEAR	16	Check seal housing
SENSOR DRIFT	7	Verify sensor

SERVICE NOTES

Check the current revision before using a recorded action.